



**DEMOLITION NOTES**

1. Remove (E) tank slab, drive slab, underground tanks, underground lines, vent lines and risers, and hoists.
2. Remove (E) ~~\_\_\_\_\_~~ pump islands, light poles, sign poles, and all other aboveground improvements. (E) service station building to remain.
3. Backfill all excavated areas with engineered backfill material compacted to 90% per Tosa specifications.
4. Patch back all area disturbed by construction with 3" asphalt over 5" of base rock per Tosa specification.

*Underground features shown on this drawing are for graphic purposes only. Actual locations must be field verified.*

PP'D	DRAWN BY	CHP	<b>SERVICE STATION 0843</b> PACIFIC AVENUE & WEBSTER STREET ALAMEDA, CALIFORNIA GENERAL ARRANGEMENT
	CHECKED BY		
	APPROVED		
	DATE	8-2-91	DRAWING NO.
	SCALE	1" = 10'	UNOCAL 

