

DAMES & MOORE
Engineering & Environmental Consultants

2101 Webster St. #300
Oakland, California 94612
(510) 839-3600

Offices Worldwide

Our facsimile number is:
(510) 839-4461

Our transmitting equipment is:
Canon FAX-630

Our receiving equipment is:
OMNIFAX PPI

Date

7/07/92

Time Sent (Pacific)

4:55

a.m./p.m.

Charge Information

Task No./

Owner

Sequence

Work Item

Office

037	15	051	70	X	043
-----	----	-----	----	---	-----

To

Name: Scott Seery

Organization: ACH

Facsimile

Number: (510) 569-4757

From

Name: Erik Skov

Direct Number: (510) 208-1 382

Message/Instructions

Scott, as per your request. Sorry the drawing got a little busy. If you have any questions give me a call. I will be out of the office tomorrow in Palo Alto and I will try giving you a call. If you need to leave me a message call my voice mail @ (415) 243-3898

Regards Erik Skov

Cover sheet plus

2

pages transmitted

CONSTITUENT

Sample No.	Gas	Diesel	B*	T*	E*	X*	Lead
DTC5-1	ND	ND	ND	ND	ND	ND	27
DTC5-2	ND	ND	10	ND	ND	17	30
RTCS-1	ND	ND	ND	ND	ND	ND	27
RTCS-2	ND	ND	ND	10	10	30	31
UTCS-1	1100	140	7,300	2,800	44,000	20,000	40
UTCS-2	810	80	4,800	1,400	37,000	16,000	45
RDCS-1	5.5	ND	440	1000	200	1200	60
DDCS-1	7.5	ND	700	310	310	960	52
UTCS-3	ND	ND	ND	ND	ND	ND	31
UTCS-4	ND	ND	ND	ND	ND	ND	39
UTCS-5	ND	ND	ND	NA	ND	ND	26
UTCS-6	ND	NA	ND	ND	ND	ND	46
DDCS-2	ND	ND	ND	ND	ND	ND	45
RTVCS-1	ND	ND	ND	ND	ND	ND	26

} dispensers

* Reported in $\mu\text{g}/\text{kg}$ (ppb) all other values in ppm.

Questions:

Lead ?

RDCS-1 / DDCS-1 → collected after overexcavation?

which sample was DTC5-1 ad-2 ?