PROPOSED INTERIM CORRECTIVE ACTION
AND PRELIMINARY SOIL & GROUNDWATER
ASSESSMENT FOR LIVERMORE HONDA
LOCATED AT 3800 FIRST STREET
LIVERMORE, CALIFORNIA
APRIL 2, 1993

Programme State Comments

PREPARED FOR:
MR. EDWIN SPENCER
880 COLUMBINE COURT
DANVILLE, CALIFORNIA 94526

BY:

SOIL TECH ENGINEERING, INC.
298 BROKAW ROAD
SANTA CLARA, CALIFORNIA 95050

SOIL TECH ENGINEERING, INC.

LIST OF FIGURES

FIGURE 1 ... SITE VICINITY MAP SHOWING 3800 FIRST STREET, LIVERMORE, CALIFORNIA.

FIGURE 2 ... SITE PLAN SHOWING LOCATIONS OF PROPOSED EXPLORATORY BORINGS AND MONITORING WELLS.

LIST OF APPENDICES

APPENDIX "A" ... SITE VICINITY MAP AND SITE PLAN.

APPENDIX "B" ... SITE GRADING AND BACKFILLING, STANDARD OPERATION PROCEDURES, VOLUME OF WATER IN CASING OR HOLE, SAMPLE MANAGEMENT AND GENERAL FORMAT.

APPENDIX "C" ... OUTLINE OF DRUM HANDLING PROCEDURES.

APPENDIX "D" ... HEALTH AND SAFETY PLAN, AND TYPES OF PROTECTIVE CLOTHING AND RESPIRATION THAT SHOULD BE USED AT HAZARDOUS WASTE SITES.

APPENDIX "E" ... ALAMEDA COUNTY HEALTH CARE SERVICES AGENCY
DEPARTMENT OF ENVIRONMENTAL HEALTH--UST LOCAL
OVERSIGHT PROGRAM'S LETTER TO MR. EDWIN SPENCER.

TABLE OF CONTENTS	Page No.
LETTER OF SUBMITTAL	1-2
INTRODUCTION	3
SITE LOCATION	3-4
BACKGROUND	4
PROPOSED SCOPE OF WORK	4-6
TASK 1 - PREPARATION OF A SITE SAFETY PLAN	6
TASK 2 - OBTAIN PERMITS	6
TASK 3 - EXPAND EXCAVATION	6-7
TASK 4 - SAMPLE STOCKPILED SOIL FOR DISPOSAL	7
TASK 5 - DRILL AND INSTALL THREE MONITORING WELLS	8-10
TASK 6 - DEVELOP WELLS AND SAMPLE GROUNDWATER	10-11
TASK 7 - ANALYZE SAMPLES AT A LABORATORY	11
TASK 8 - EVALUATE DATA AND PREPARE REPORT	11-12
APPENDIX "A"	
FIGURE 1 - VICINITY MAP	M1
FIGURE 2 - SITE PLAN	М2
APPENDIX "B"	
SITE GRADING AND BACKFILLING DRILLING AND SOIL SAMPLING PROCEDURE BORING LOG SHEET MONITORING WELL INSTALLATION WELL DETAILS SHEET	SGB1-SGB2 SOP1-SOP2 SOP3 SOP4-SOP5 SOP6

TABLE OF CONTENTS CONT'D

Page No.

APPENDIX "B" CONT'D

WELL DEVELOPMENT AND WATER LEVEL MEASUREMENTS	SOP7
MONITORING WELL SURVEY SHEET	SOP8
GROUNDWATER SAMPLING	SOP9-SOP10
WELL MONITORING/SAMPLING SHEET	SOP11
VOLUME OF WATER IN CASING OR HOLE	SOP12
CHAIN-OF-CUSTODY RECORD	SOP13
SAMPLE MANAGEMENT	SOP14-SOP19
GENERAL FORMAT SHEET	SOP20

APPENDIX "C"

OUTLINE OF DRUM HANDLING PROCEDURES

ODHP1-ODHP5


APPENDIX "D"

HEALTH AND SAFETY PLAN	HSP1-HSP9
TYPE OF PROTECTIVE CLOTHING AND RESPIRATION	TPCR1-TPCR4

APPENDIX "E"

ALAMEDA COUNTY HEALTH CARE SERVICES AGENCY DEPARTMENT OF ENVIRONMENTAL HEALTH--UST LOCAL OVERSIGHT PROGRAM'S LETTER TO MR. EDWIN SPENCER.





Soil, Foundation and Geological Engineers

298 BROKAW ROAD, SANTA CLARA, CA 95050 (408) 496-0265 OR (408) 496-0266

April 2, 1993

File No. 11-92-528-ST

Mr. Edwin Spencer 880 Columbine Court Danville, California 94526

SUBJECT: PROPOSED WORK PLAN FOR INTERIM CORRECTIVE ACTION AND

PRELIMINARY SITE ASSESSMENT FOR LIVERMORE HONDA PROPERTY

Located at 3800 First Street, in

Livermore, California

Dear Mr. Spencer:

Soil Tech Engineering, Inc. (STE) is pleased to submit this proposed work plan for interim corrective action and preliminary soil & groundwater assessment in the vicinity of removed underground storage tanks as requested by Alameda County Health Care Services Agency Department of Environmental Health--UST Local Oversight Program (ACDEH-USTOP) letter dated January 27, 1993.

The interim corrective action/preliminary soil & groundwater assessment is consistent with STE's proposed work plan dated March 4, 1993. The proposed work includes soil excavation to extent feasible, soil verification sampling, stockpile soil sampling, proper soil disposal, drilling 3 to 6 exploratory borings and converting three of the borings into monitoring wells.

If you have any questions or require additional information, please feel free to contact our office at your convenience.

Sincerely,

SOIL TECH ENGINEERING, INC.

NOORODDIN AMELI PROJECT ENGINEER

FRANK HAMEDI-FARD GENERAL MANAGER LAWRENCE KOO, P. E.

C. E. #34928

PROPOSED WORK PLAN
FOR INTERIM CORRECTIVE ACTION AND
PRELIMINARY SOIL & GROUNDWATER ASSESSMENT
AT LIVERMORE HONDA
LOCATED AT 3800 FIRST STREET
LIVERMORE, CALIFORNIA
APRIL 2, 1993

INTRODUCTION:

A work plan for a preliminary site assessment (PSA) at Livermore Honda located at 3800 First Street in Livermore, was requested by the Alameda County Department of Environmental Health-UST Oversight Program (ACDEH--USTOP) in a letter dated January 27, 1993 (Appendix "E").

An evidence of inadvertent fuel leak at the location of the recently removed three underground fuel storage tanks. Soil sampling was conducted by Soil Tech Engineering, Inc. (STE) to characterize the degree and extent of fuel concentrations in the tank excavation. This work plan proposes a scope of work to implement a preliminary investigation of the soil and groundwater at the site.

SITE LOCATION:

The site is located at 3800 First Street, in Livermore, California, at intersection of First Street and Portola Avenue (Figure 1).

Livermore Honda is located in an area of light industry and residential. The site is used as an auto dealership. A site map illustrating the location of the building, the former underground storage tanks, and the proposed monitoring wells is presented as Figure 2.

BACKGROUND:

In December 1992, three underground storage tanks were removed. A 3,000 gallon and 550 gallon tanks contained gasoline; and a 550 gallon tank contained waste oil (Figure 2). The tanks were removed by Alpha Geo Services while the required tank pit soil sampling were performed by STE. Laboratory results of soil sample analysis indicated a presence of moderate levels of TPH as gasoline [98 milligrams per kilogram (mg/Kg)] in only one area, and BTEX concentrations were less than 1 mg/Kg in the gasoline tank area. The waste oil tank excavation area also showed very low levels of TPH as diesel (1.6 mg/Kg). Toluene, Ethylbenzene and Total Xylenes were less than 0.01 mg/Kg, but Total Oil and Grease (TOG) was 95 mg/Kg. No Volatile Organic compounds were detected in the waste oil soil sample.

PROPOSED SCOPE OF WORK:

This proposed work plan presents the overall scope of work for site remediation, soil remediation clean-up criteria, the excavation and monitoring procedures, and to conduct a preliminary subsurface and groundwater investigation by installing six exploratory borings and converting three borings into monitoring wells.

The scope of work proposed to assess the presence and possible extent of fuel hydrocarbon contamination in soil and groundwater in the vicinity of removed underground storage tanks at the subject site is as follows:

- 1. Prepare health and safety plan.
- 2. Obtain all necessary permits.
- 3. Expand the former underground tank excavation and remove soil containing high levels of hydrocarbons.
- 4. Sample the excavated material for proper disposal.
- 5. Drill six soil borings and install three groundwater monitoring wells.
- 6. Develop and sample wells.
- 7. Analyze samples at a laboratory.
- 8. Evaluate data and prepare report.

All proposed work will be conducted in accordance with our Standard Operation Procedures (SOP) and San Francisco Regional Water Quality Control Board (RWQCB) Tri-Regional Fuel Leak Guidelines, LUFT Manual and local requirements.

Each of the proposed tasks described above are discussed in detail below.

Task 1. Prepare a Health and Safety Plan

per OSHA requirements, a site Health and Safety Plan has been prepared. The main purpose of the plan is to protect the staff including uninvolved personnel against potential physical and chemical hazards associated with excavation, drilling, sampling and field activities. All employee and subcontractor will be required to read and comply with the plan. The site Health and Safety Plan is developed for the protect and attached in Appendix "D".

Task 2. Obtain Permits

All necessary permits for excavation and drilling will be obtained from the regulatory agencies prior to initiating any work.

Task 3. Expand Excavation

We propose to expand the excavation around the former tank areas and the pipeline to remove soil containing fuel hydrocarbons.

During excavation, we will obtain samples by partially filling stainless steel sample tubes with excavated soil and using a photo-ionization detector (PID) to detect volatile components. This process will involve capping and agitating the tube to allow volatilization of petroleum hydrocarbons from the soil, then piercing the sample cap with the PID and collecting headspace readings.

STE will continue to expand the excavation until headspace readings of soil from the limits of the excavation show volatile organic vapor concentrations of less than 10 parts per million (ppm), or until further excavation is not feasible.

STE will then collect conformation soil samples from the limits of the excavation. Soil samples will be collected by driving sample tubes into the walls and the bottom of the excavation. Samples will be capped with aluminum foil and plastic end caps, sealed with tape, and stored in an ice-chilled cooler pending transport to a state-certified laboratory.

The excavated soil will be added to the stockpiled soil from tank removal. STE will assist with the selection of suitable backfill material and direct the placement of this material in lifts of no more than 10 inches to be compacted with mechanical equipment. STE will provide in-place density testing of the fill material. We propose to have the fill compacted to a minimum relative compaction of 90 percent.

Task 4. Sample Stockpiled Soil for Disposal

Stockpiled soil will be sampled in accordance with Bay Area Air Quality Management District Regulations for assessing the most cost-effective method of disposal.

Task 5. Drill and Install Three Monitoring Wells

STE will drill approximately six exploratory borings and convert three borings to monitoring wells using the hollow-stem auger drilling equipment. The tentative locations of the proposed monitoring wells are shown in Figure 2. The actual location and depths of the monitoring wells will be determined in the field based on the results of laboratory from the excavation, the depth to ground-water, depths and thicknesses of sediments encountered, and types.

Permits for monitoring well installation will be obtained from the Alameda County Water District--Zone 7 prior to initiating work.

The proposed soil borings and monitoring wells will be drilled and installed near the former tank excavation area after the excavated area has been properly backfilled (with one monitoring well less than 10 feet from down-gradient of the excavation area).

Soil samples will be collected at 5-foot intervals from the borings for lithologic description. Selected soil samples will also be retained for possible chemical analysis for petroleum

hydrocarbons. Samples for chemical analysis will be collected in clean brass liners using a Modified California sampler. These samples will be immediately sealed and placed in chilled coolers for transport to the laboratory with the proper chain-of-custody attached. Soil samples will be analyzed for Total Petroleum Hydrocarbons as gasoline and/or diesel (TPHg and TPHd), Benzene, Toluene, Ethylbenzene and Total Xylenes (BTEX), Total Oil and Grease (TOG) and Volatile Organic Compounds (VOC's).

The proposed monitoring wells will be constructed using 2-inch diameter, factory-slotted PVC casing. The well annulus outside the perforated interval will be backfilled with an appropriately-sized sand pack. Bentonite pellets and a cement-bentonite slurry will be placed above the sand pack to the land surface to seal the annular space of the borehole. A protective locking steel cover or Christy box will then be placed over the top of each well.

The elevation of each well will be surveyed to the nearest 0.01-foot and tied to an existing elevation benchmark to allow accurate measurement of the groundwater elevation.

Drilling and sampling equipment and well materials will be steam-cleaned before use. Power, water and an area for cleaning equipment are to be provided at the site.

Waste soil generated during the drilling of the monitoring wells will be placed on plastic sheeting and stockpiled on-site.

Waste water produced during the development and sampling of the proposed wells will be placed in the drum and stored on-site pending on the results of laboratory for proper disposal.

Task 6. Develop Wells and Sample Groundwater

The three newly installed monitoring wells will be developed by pumping, surging and/or bailing to remove fine particles near the well screen and improve hydraulic communication with the surrounding formation. Water clarity, Ph, temperature, specific conductance and volume extracted will be measured during the development process to gauge its progress.

Groundwater sampling will involve pumping and/or bailing approximately three to five well casing volumes of water out of the well prior to sampling. Only wells without visible floating product will be sampled. Water clarity, pH, specific conductance, temperature and volume extracted will be measured during purging to determine when to sample, as applicable.

Groundwater samples will be collected using a Teflon bailer. Samples will be transferred into 40-ml VOA vials with Teflon septa and 1-liter, amber-colored, glass bottles. The samples will be stored in a chilled cooler for delivery to the laboratory with chain of custody attached. A field blank sample and duplicate will also be collected for quality control purposes.

Measuring depth-to-groundwater and floating product, if any, will be completed using an electronic product/water interface sounder and/or a thin rod marked with special water- and gasoline-finding paste. In addition, depth-to-groundwater also will be measured using an electric water-level meter when possible.

Task 7. Analyze Samples at a Laboratory

Approximately three groundwater samples (three well samples and one duplicate) will be analyzed by a state-certified laboratory for Total Petroleum Hydrocarbons as both diesel and gasoline (TPHd and TPHg) and fuel constituents (BTEX) using modified EPA Method 8015 or 8020. In addition, selected soil samples will be analyzed for TPH as diesel and gasoline and BTEX using EPA Method 8015 and 8020, VOC's by EPA Method 8010 and TOG by EPA Method 503D.

Task 8. Evaluate Data and Prepare Report

A report will be prepared summarizing the data and presenting the resulting interpretations, assessments and recommendations for additional investigations or alternative remedial actions, if deemed necessary. The report will include detailed descriptions of the methodologies and technical rationale used to collect and analyze data and the technical rationale for the conclusions reached.

The report will describe the types(s) of geologic materials encountered, the occurrence, concentrations and distribution of


stight also be

File No. 11-92-528-ST

petroleum hydrocarbons and related compounds in soil and groundwater and interpretations concerning hydrogeologic conditions at the site. The report will also contain lithologic logs prepared during drilling activities, including well construction design, geologic cross sections, chemical analysis data and other documentation.

A P P E N D I X "A"


SOIL TECH ENGINEERING, INC.





Thomas Brothers Map 1993 Edition San Francisco, Alameda, and Contra Costa Counties

Page 51 A5



A P P E N D I X "B"

SOIL TECH ENGINEERING, INC.

SITE GRADING AND BACKFILLING FOR LIVERMORE HONDA PROPERTY LOCATED AT 3800 FIRST STREET LIVERMORE, CALIFORNIA

Site clearing, placement of fill and the control of grading operations at the site must be conducted in accordance with the following recommendations and under a supervision of a Project Engineer.

- 1) The depression left by the removal of contaminated soil should be cleaned of all debris and backfilled with clean soil. This backfill must be engineering fill. This operation must be conducted under the supervision of the Project Engineer.
- 2) All engineering fill, whether native or imported soil, should be placed in uniform horizontal lifts not more than 6 to 8 inches in uncompacted thickness and compacted to not less than 90% relative compaction according to ASTM D1557-83 procedure.
- 3) Before compaction begins, the fill material whether native or imported soil shall be brought to water content that will permit compaction by either:
 - A) Aerating the material if it is too wet, or
 - B) Spraying the material with water if it is too dry.

Each lift shall be thoroughly mixed before compaction. No rocks larger than 4 inches in diameter should be used.

- 4) No soil shall be placed or compacted during periods of rain nor on ground which is not drained of all free water. Soil which has been soaked and wetted by rain or any other cause, shall not be compacted until completely drained and the moisture content is within the limits herein described or approved by the Project Engineer. Prior approval by the Project Engineer shall be obtained before continuing the grading operations.
- 5) The contractor shall conduct all grading operations in such a manner as to preclude wind blow dirt, dust and related damage to neighboring properties. The means of dust control shall be left to the discretion of the contractor. the contractor shall assume liability for claims related to wind blow materials.
- 6) Any import soil for engineering fill shall be approved by the Project Engineer before the grading operation.
- 7) All grading shall be observed and approved by Project Engineer and shall prepare a final report upon completion of the backfilling operations.

DRILLING AND SOIL SAMPLING PROCEDURE

A truck-mounted drill rig, using a continuous, solid-flight, hollow stem auger will be used in drilling soil borings to the desired depths.

Prior to drilling, all drilling equipment (i.e. auger, pin, and drilling head) will be thoroughly steam-cleaned to minimize the possibility of cross-contamination and/or vertical migration of possible contaminants.

In addition, prior to obtaining each individual soil sample, all sampling tools, including the split-spoon sampler and brass liners will be thoroughly washed in a Tri-Sodium Phosphate (TSP) solution followed by a rinse in distilled water.

During the drilling operation, relatively undisturbed soil samples will be taken from the required depth by forcing a 2-inch I.D., split-spoon sampler insert with a brass liner into the ground by means of a 140-lb. hammer, falling 30-inches or by hydraulic forces, at various depths.

The samplers will contain relatively undisturbed soil. In general, the first section of soil from the sampler (shoe) will be used in the field for lithologic inspection and evidence of contamination. The selected brass liner will be immediately trimmed, and the ends of the brass liner will be covered tightly

with aluminum foil and plastic caps, sealed with tape, labeled, placed in a plastic bag and store in an ice chest on blue ice in order to minimize the escape of any volatiles present in the samples. Soil samples for analysis are subsequently sent to a State Certified Hazardous Waste Laboratory accompanied by a chain-of-custody record.

Soil samples collected at each sampling interval will be inspected for possible contamination (odor or peculiar colors). Soil vapor concentrations are measured in the field by using Photoionization Detector (PID), PhotoVac-Tip Air Analyzer. The purpose of this field analysis is to qualitatively determine the presence or absence of hydrocarbons and to establish which soil samples will be analyzed at the laboratory. The soil sample is sealed in a zip-lock plastic bag and placed in the sun to enhance volatilization of the hydrocarbons from the sample. The data is recorded on the drilling log at the depth corresponding to the sampling point.

Other soil samples may be collected to document the stratigraphy and estimate relative permeability of the subsurface materials.

Soil tailings obtained during drilling will be stored on-site in steel drums, pending the analytical test results, for proper disposal.



Blows/6

Inches

Jinp le nallry

SOIL TECH ENGINEERING

		Soll, Foot	ECH LNGI	ylent Englisons		
	290 mic	3 , מעמוז זאניכ	אווא מאוא, כא	95050 a	rile tto.	
	1				Date	
	Δ				Ny	
Job					_	
Site D	escript	don			_ (continued on	reverse side)
Type o	f Dril	n Rig			_ Nole Dia	
(NOTE	MATER	LEVEL, T	rine, daż	E AT EID OF LOG	CAVING, ETC.)	
					Datum	
· · · · · · · · · · · · · · · · · · ·	. Sai					
lows/6 nches	loc.	No.	Depti	Soil Cla	ssification	renetrometer
·	<u> </u>			<u> </u>		
	-					
			2			· ·
	_		3_			1
	_		4, -			
	-		5_			
	-		6_			
				,		
			8 -			
			1 1			
	-		2			
			0}			
	_	<u> </u>				
· · · · · · · · · · · · · · · · · · ·	-		_ 2			
	_					
			5 -			· .
	-		6-			
	-		7-			
			8 -			
	_					
	- -	-	- 9			
	[]	1	1 0 7			

SOP3

MONITORING WELL INSTALLATION

Prior to well installation, all the necessary permits will be obtained from the local regulatory agencies.

The boreholes for monitor wells are drilled with the diameter at least two inches larger than the casing outside diameter (O.D.).

Monitor wells will be cased with threaded factory perforated and blank, schedule 40 P.V.C. The perforated interval consists of slotted casing, generally 0.010 to 0.040 inch wide by 1.5 inch long slots, with 42 slots per foot (slots which match formation grain size as determined by field grain-size distribution analysis), a P.V.C. cap is fastened to the bottom of the casing (no solvents, adhesive, or cements are used). The well casing is thoroughly washed and steam-cleaned.


After setting the casing inside the borehole, kiln dried sand or gravel filter-material is poured into the annular space from the bottom of the boring to 2 feet above the perforated interval. A 1 to 2-feet thick bentonite plug will be placed above this filter material to prevent grout infiltration into the filter material. Approximately 1 to 2 gallons of distilled water will be added to hydrate the bentonite pellets. The well is then sealed from the top of the bentonite seal to the surface with concrete or neat cement (containing about 5% bentonite) (see Well Construction Detail).

For protection from vandalism and surface water contamination, Christy boxes with a special type of Allen screw are installed around the well head, (for wells in parking lots, drive-ways and building areas). Steel stovepipes with padlocks are usually set over well heads in landscaped areas.

In general, groundwater monitoring wells shall extend to the base of the upper aquifer, as defined by the consistent (less than 5 feet thick) clay layer below the upper aquifer, or at least 10 to 15 feet below the top of the upper aquifer, whichever is shallower. The wells shall not extend through the laterally extensive clay layer below the upper aquifer. The wells shall be terminated 1 foot to 2 feet into such a clay layer.

WELL DETAILS

PROJECT NUMBER: CASING ELEVATION:	PROJECT NAME:	BORING/WELL NO
PROJECT NUMBER: CASING ELEVATION:	•	•
	PROJECT NUMBER:	CASING ELEVATION:
THE L DEDUCE NO.	••	•



A.	Total Depth:
в.	Boring Diameter:
	Drilling method:

- C. Casing Length:

 Material:
- D. Casing Diameter:
- E. Depth to Perforations:
- F. Perforated Length:_____

 Perforated Interval:_____

 Perforation Type:_____

 Perforation Size:_____
- G. Surface Seal:_________
 Seal Material:______
- H. Seal:_______
 Seal Material:_____
- I. Gravel Pack:

 Pack Material:

 Size:
- J. Bottom Seal:

 Seal Material:


WELL DEVELOPMENT AND WATER LEVEL MEASUREMENTS

For all newly-installed groundwater monitoring wells, the well casing, filter pack and adjacent formation shall be cleared of disturbed sediment and water.

Well development techniques will include pumping, bailing, surging, swabbing, jetting, flushing and air lifting by using a stainless steel or Teflon bailer, submersible stainless steel pump, or air lift pump. The well development will continue until the groundwater appears to be relatively free of fine-grained sediments and/or until field measurements of pH, electrical conductivity and temperature stabilize.

To assure that cross-contamination does not occur between wells, all well development tools be thoroughly washed in a Tri-Sodium Phosphate (TSP) solution followed by a rinse in distilled water or steam-cleaned before each well development.

Subsequent to well installation, the well(s) will be surveyed to the nearest benchmark to an accuracy of 0.01 feet, in order to accurately measure the groundwater elevation. The depth to the static water surface in all wells will be measured monthly.



SOIL TECH ENGINEERING

Soll, Foundation and Geological Engineers
298 BROKAW ROAD, SANTA CLARA, CA 95050 ■ (408) 866-0919 ■ (415) 791-6406

MONITORING WELL BURVEY SHEET

FACILITY	NAME AND	ADDRESS: _				,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
		_				
DATE WEI	LLS SURVEYE	D:				
		FIEL	D ACTIVIT	<u>(ES</u>		
	י י	UN 1	מו	UN 2	R	UN 3
WELL NUMBER	ROD	RIM ELEVATION	ROD	RIM	ROD	RIM ELEVATION
					<u></u>	
	•	•				
			•		· · · · · · · · · · · · · · · · · · ·	
		-	•			
	<u> </u>					<u></u>
•	•		<u> </u>			•
	•				94-14-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-	
		<u>`</u>				
WARNING:	HAVE YOU S	URVEYED <u>ALL</u>	WELLS?	LOCATED ALL	WELLS?	
	HAVE YOU CON ADJACEN	HECKED FOR T PROPERTIE	AND SURVE S OR PROP	YED EXISTIN ERTIES ACRO	G MONITOR SS THE ST	ING WELLS REET?
	DO WE HAVE	ACCURATE S	KETCHES A MAKE THEM	T 1"=30' (A	ND 1"=100	' 1F
\survey	— - ,	·				

GROUNDWATER SAMPLING

Prior to collection of groundwater samples, all of the sampling equipment (i.e. bailer, cables, bladder pump, discharge lines and etc...) are cleaned by pumping TSP water solution followed by distilled water.


Prior to purging the well, "Water Sampling Field Survey Forms" will be filled out (depth to water level and total depth of well and well casing volume calculated). The well will be then bailed or pumped to remove four to ten well-volumes or until the discharged water temperature, conductivity and pH stabilize. "Stabilized" is defined as three consecutive readings within 15% of one another.

The groundwater sample will be collected when the water level in the well recovers to 80% of its static level.

Forty milliliter (ml.) glass Volatile Organic Analysis (VOA) vials with Teflon septa will be used as sample containers. The groundwater sample will be decanted into each VOA vial in such a manner that no air space is present. The cap is quickly placed over the top of the vial and securely tightened. The groundwater sample will be labeled and refrigerated for delivery with proper chain-of-custody to the laboratory. Chain-of-custody information should include a sample identification number, job identification number, date, time, type of analysis requested, and the sampler's name.

File No. 11-92-528-ST

In general, a laboratory-cleaned bailer will be used for each monitoring well sampled.



SOIL TECH ENGINEERING

Soil, Foundation and Geological Engineers
298 BROKAW ROAD, SANTA CLARA, CA 95050 ■ (408) 866-0919 ■ (415) 791-6406

WELL MONITORING/SAMPLING

	Name:			Date:_			····		
	FACILITY NAME AND ADDRESS:								
			:				-		
			FIELD	ACTIVITIES					
	DEVELOPING	MONITO	RING P	URGING (PUMP/B	BAIL)	SAMPLING			
WELL NUMBER	WELL <u>DEPTH</u>	WATER DEPTH		SHEEN S PRESENCE	ODOR	VOLUME <u>WATER</u>			
			· · · · · · · · · · · · · · · · · · ·						
	***************************************	<u></u>							
						<u> </u>	<u> </u>		
									
	<u> </u>				·				
									
				<u> </u>					

SKETCH -- REMARKS

Volume of Water in Casing or Hole

	· · · · · · · · · · · · · · · · · · ·	1		1
Diameter of Casing or Hole (In)	Gallons per foot of Depth	Cubic Feet per Foot of Depth	Liters per Meter of Depth	Cubic Meters per Meter of Depth
\~,				
1	0.041	0.0055	0.509 1.142	0.509 x 10 ⁻³ 1.142 x 10 ⁻³
1½ 2	0.092	0.0123 0.0218	2.024	2.024 x 10 ⁻³
$\begin{array}{c} 2 \\ 2\frac{1}{2} \end{array}$	0.163 0.255	0.0341	3.167	3.167 x 10 ⁻³
3	0.255	0.0341	4.558	4.558 x 10 ⁻³
3½	0.500	0.0668	6.209	6.209 x 10 ⁻³
4	0.653	0.0873	8.110	8.110 x 10 ⁻³
41/2	0.826	0.1104	10.26	10.26×10^{-3}
5	1.020	0.1364	12.67	12.67×10^{-3}
5½	1.234	0.1650	15.33	15.33×10^{-3}
6	1.469	0.1963	18.24	18.24 x 10 ⁻³
7	2.000	0.2673	24.84	24.84×10^{-3}
8	2.611	0.3491	32.43	32.43×10^{-3}
9	3.305	0.4418	41.04	41.04×10^{-3}
10	4.080	0.5454	50.67	50.67×10^{-3}
11	4.937	0.6600	61.31	61.31 x 10 ³
12	5.875	0.7854	72.96	72.96 x 10 ³
14	8.000	1.069	99.35	93.33 A IV
16	10.44	1.396	129.65	123.03 A 10
18	13.22 16.32	1.767	164.18 202.68	164.18 × 10 ³ 202.68 × 10 ³
20 22	19.75	2.182 2.640	245.28	245.28 x 10 3
24	23.50	3.142	291.85	291.85 x 10 3
26	27.58	3.687	342.52	342.52×10^{-3}
28	32.00	4.276	397.41	397.41 x 10 3
30	36.72	4.909	456.02	456.02 x 10 3
32	41.78	5.585	518.87	518.87×10^{-3}
34	47.16	6.305	585.68	585.68×10^{-3}
36	52.88	7.069	656.72	656.72×10^{-3}
			<u> </u>	

¹ Gallon = 3.785 Liters

 $^{1 \}text{ Meter} = 3.281 \text{ Feet}$

¹ Gallon Water Weighs 8.33 lbs. = 3.785 Kilograms

¹ Liter Water Weighs 1 Kilogram = 2.205 lbs.

¹ Gallon per foot of depth = 12.419 liters per foot of depth
1 Gallon per meter of depth = 12.419 x 10 ° cubic meters per meter of depth



SOIL TECH ENGINEERING

Soil, Foundation and Geological Engineers

SAMPLE MANAGEMENT

Sample Type: Soils, Oils, Solvents, Polids, Highly Contaminated Liquids (c)

General Composition	Sample Volume	Sample Container	Preservative	Holding Time			
				(recommended/regulatory)			
Weak Acids and Bases		plastic or glass					
Photosensitive material	5	amber glass					
Volatile organics		40 ml glass vial with TFE lined septum	ı				
Non-volatile organics		glass with TFE lined	cap				
Measurement - General C	hemical Categorie	s, Inorganic					
Inorganics, general		plastic or glass					
Metals, total		plastic or glass					
Measurement - General C	hemical Categorie	s, Organic					
Acid extractables		glass with TFE lined	cap				
Base/neutral extractabl	es	glass with TFE lined	cap				
Measurement Specific Chemicals - Inorganic							
Hydrofluoric acid		plastic					
Phosphoric acid		plastic					

Sample Type: Waste

General Composition	Sample Volume	Sample Container	Preservative	Holding Time (d)
				(recommended/regulatory)
Measurement - Specific	Chemicals, Inorganic	<u>.</u>		•
Ammonia			add 1 ml conc H ₃ PO ₄	24 hrs
Arsenic			add 6 ml conc HNO3/L	6 months
Chlorine			∞ol 4°C	24 hrs
Chromium VI			add 6 ml conc H ₂ SO ₄ /I	24 Hrs
Cyanide, total			add 2.5 ml of 50% NaOH/L, cool 4°C	24 hrs
Fluoride			cool 4°C	7 days
Mercury, total			add 5 ml conc HNO3L	38 days
Mercury, dissolved			filter, add 5 ml conc HNO ₃ /L	38 days
Selenius			add 5 ml conc HNO3/L	6 months
Sulfide			add 2 ml conc HC1/1	24 hrs
Zinc		-	add 2 ml conc HC1/1	-
Sample	Type: Soils, Oils,	Solvents, Solids,	Highly Contaminated Li	quids (c)
Strong acids, pH<2		glass		
Strong bases, pH>12.5		plastic		

Sample Type: Water and Wastewater

General Composition	Sample Volume	Sample Container	Preservative	Holding Mins (4)
	Down Programme	Dumple Container	rieservacive	Holding Time (d) (recommended/regulatory)
Sulfate	50 ml	plastic or glass	∞ol 4°C	7 days/28 days
Sulfide	500 ml	plastic or glass	cool 4°C, add 4 drops 2N Zn acetate/100 ml	24 hrs/28 days
Sulfite	50 ml	plastic or glass	determine on site	no holding
Measurement - Specific	Chemicals, Organic			
NTA	50 ml	plastic or glass	∞ol 4°C	24 hrs
		waterline & center		
Measurement - Physical	Properties			
Acidity Alkalinity pH			cool 4°C cool 4°C determine on site cool 4°C	24 hrs 24 hrs 6 hrs
Measurement - General (Chemical Categories	, Inorganic		
Metals, dissolved			filter on site, add 5 ml conc HNO ₃ /L	6 months
Metals, total			add 5 ml conc HNO3/L	6 months
Measurement - General C	Chemical Categories	, Organic	-	
Phenolics			add H_3PO_4 to pH 4 and 1 g $CuSO_4/L$, cool 4°C	24 hrs

Sample Type: Water and Wastewater


General Composition	Sample Volume	Sample Container	Preservative	Holding Time (d)
				(recommended/regulatory)
Measurements - Specific	Chemicals, Inorg	anic		
Ammonium	500 ml	plastic or glass	cool, 4° C, add $_{12}$ SO ₄ to pH<2	24 hr/28 days
Boron	100 ml	plastic	none required	28 days/28 days
Chlorine	200 ml	plastic or glass	determine on site	no holding
Chromium VI	300 ml	plastic or glass, rinse with 1:1 HNO ₃	c∞l, 4°C	24 hrs/28 days
Cyanide, total	500 ml	plastic or glass add NaOH to pH>12	c∞l, 4°C, dark	24 hrs/14 days
Cyanide, amenable to chlorination	50 ml	plastic or glass	add 100 mg NaS_2O_3	
Fluoride	300 ml	plastic	none required	7 days/28 days
Iodide	100 ml	plastic or glass	cool, 4°C	24 hrs/ -
Iodine	500 ml	plastic or glass	determine on site	1/2 hr/-
Mercury, total	500 ml	plastic or glass rinsed with 1:1 HNO ₃	∞ 1, 4°C.add HNO ₃ to pH<2	28 days/28 days
Mercury, dissolved	100 ml	plastic or glass	filter on site add HNO ₃ to pH<1	glass: 38 days hard plastic:
Nitrate	100 ml	plastic or glass	∞ 1, 4°C add H_2 SO ₄ to pH<2	24 hrs/48 hrs
Nitrate & nitrate	200 ml	plastic or glass	∞ 1, 4°C add H ₂ SO ₄	24 hrs/28 days
Nitrate	100 ml	plastic or glass	∞ol, 4°C or freeze	

Sample Type: Water and Wastewater

General Composition	Sample Volume	Sample Container	Preservative	Holding Time (d)					
				(recommended/regulatory)					
Measurement - General Chemical Categories, Organic									
Acid extractables		2 liter glass with TFE lined cap							
Base/neutral extractable	le	2 liter glass with TFE lined cap							
MBA 's	250 ml	plastic or glass	c∞l, 4°C	24 hr					
Oil and Grease	1000 ml	glass, wide mouthed, calibrated	cool, 4° C, H_2 SO ₄ to pH<2	24 hr/28 days 24 hr/28 days					
Organics		glass rinsed with organic solvents, TFE cap							
Phenolics	500 ml	glass		24 hr/28 days					
Purgeables by purge and trap	50 ml	glass, TFE lined cap							

Sample Type: Water and Wastewater (a,b,c)

General Composition	Sample Volume	Sample Container	Preservative	Holdin Time (d)
				(recommended/regulatory)
Nonvolatile organics		2 liter glass with TFE lined cap		
Photosensitive material	s	1 liter amber glass		
Volatile organics		40 ml glass vial with TFE lined cap (collect in duplicate)		
Volatile	100 ml	Plastic or glass	cool, 4°C	7 days
Measurement - Physical	Properties			
Acidity	100 ml	plastic or borosilicate glass	e cool, 4°C	24 hr/14/days
Alkalinity	200 ml	plastic or glass	cool, 4°C	24 hr/14/days
pН	25 ml	plastic or glass	determine on sit	te 2 hr/2 hr
Temperature	1000 ml	plastic or glass	determine on sit	ce no holding
Measurement - General C	hemical Categories	, Inorganic		
metals, dissolved	200 ml	plastic(g) or glass	filter on site	(f) 6 mos (e)
metals, total	100 ml	plastic(g) or glass rinsed with 1:1 HNO ₃	HNO_3 to $pH<2$ (g)	6 mos/6 mos (e)



SOIL TECH ENGINEERING

Soil, Foundation and Goological Engineers
298 BROKAW ROAD, SANTA CLARA, CA 95050 m (408) 866-0919 m (415) 791-6406

GENERAL FORMAT SOIL SAMPLING FOR DISPOSAL and/or SITE SUPERVISION

REPRESENTATIVE		рате
FACILITY NAME AND ADDR	ESS	
FACILITY CONTACT/ENGIN	EER:	PHONE: ()
DEALER/OWNER	•	PHONE:()
CONTRACTOR	•	PHONE: ()
FIRE DEPARTMENT	:	PHONE: ()
COUNTY HEALTH DEPARTME	ENT:	PHONE:()
STATE AGENCY	•	PHONE:()
SOIL DESCRIPTION (Circ) ODOR DESCRIPTION (Circ)		TY CLAY SANDY/CLAY SILTY/SAN AINT MINOR STRONG
الله فيدن الله فيدن الله فقط الله فقط الله الله الله الله الله الله الله الل	SOIL SAMPLIN	<u>IG</u>
•		I SAMPLES TAKEN AT:(FT
	SITE SUPERVIS	
AERATION: DATE PERMI		4 BAAQMD:
•		ERATED :cu.yds.
·		IS DATE :cu.yds.
•	SOIL EXCAVATED:	qu.yds.

SOP20

A P P E N D I X "C"

SOIL TECH ENGINEERING, INC.

OUTLINE OF DRUM HANDLING PROCEDURES FOR LIVERMORE HONDA PROPERTY LOCATED AT 3800 FIRST STREET LIVERMORE, CALIFORNIA

- 1. Test material per site-specific test requirements.
- Classify Material as: Clean/Non-Hazardous.
- 3. Labeling of Drums:
 - * Pending Label: Used to describe material pending final analytical testing. Labels must be immediately affixed to drum during field work.
 - * Non-Hazardous Label: Required within 24 hours after analytical results are received.
 - * Hazardous Label: Required within 24 hours after analytical results are received.
 - * For Pick-Up Label: Must be affixed to drum prior to arranged pick-up date by certified hauler.
- 4. Remove within 21 days of generation. Empty drums, where material was disposed in bulk, <u>must</u> be removed the same day they are emptied.
- 5. Disposal of Material:
 - * Clean: Any local landfill.
 - * Non-Hazardous: Class III landfill.
 - * Hazardous: Class I landfill.

6. Manifests may be signed by the on-site contractor or consultant, owner, or other authorized representatives. The transporter should not sign the manifest.

It is the responsibility of the contractor, consultant and owner to arrange for a person to sign the manifest on the day of pick-up.

7. Reporting:

Reports shall include the following:

- * Completed soil and water worksheets.
- * Copy of the analytical results.
- * State how and where material was disposed.
- * If drums are emptied and material was disposed of in bulk, state how empty drums were handled.
- * The signed blue and yellow copies of the hazardous waste manifest.

SOIL:

- 1. Test Requirements and Methods: Per STE site-specific test requirements.
 - * TPH: EPA Method 8015.
 - * BTEX: EPA Method 8020.
 - * O&G: 503 D&E.
 - * Lead:
 - -Total Lead EPA Method 7421.

- -Inorganic (soluble) Lead: DOS Title 22, Waste Extraction Test, §22-66700.
- -Organic EPA Method 8240.
- * Ignitable:

2. Classification:

- * Clean: TPH, BTEX, O&G, VOC and non-detectable (<100 ppm).
- * Non-Hazardous if any are true:
 - -TPH less than 1,000 ppm.
 - -Lead Inorganic (soluble) Lead less than 5 ppm (STLC) or less than 100 ppm (TTLC).
 Organic Lead less than 13 ppm (TTLC).
 - -TPH greater than 1,000 ppm.

Hazardous if any are true:

- -Lead Inorganic (soluble) Lead greater than 5 ppm (STLC) or greater than 1,000 ppm (TTLC).
 - Organic Lead greater than 13 ppm (TTLC).
- -Ignitable If TPH > 1,000 ppm, then conduct Bunsen Burner Test.
 - If soil bums vigorously and persistently, soils are RCRA D001.
- * VOC less than 1,000 ppm.
- 3. Responsibility for Disposal:
 - * Clean: Consultant, contractor or owner.
 - * Non-Hazardous: Consultant, contractor or owner.

- 4. Types of Drums: DOT-17H for a solid, solidified, or sludge material.
- 5. Disposal Facility:
 - * Clean: Any local landfill.
 - * Non-Hazardous: Class III or II landfill.
 - * Hazardous: Class I landfill.

WATER:

- 1. Test Requirements and Methods: Per site-specific test requirements.
 - * TPH: EPA Method 8015.
 - * BTEX: EPA Method 602.
- 2. Classification:
 - * Clean Water: TPH and BTEX non-detectable.
 - * Hazardous:
 - -Water with dissolved product and detectable TPH and BTEX.
 - -Water with free product.
 - -Free product only.
- 3. Responsibility for Disposal:
 - * Clean: Consultant/Contractor.
 - * Non-Hazardous: Consultant, contractor or owner.

- 4. Types of Drums: DOT-17C or DOT-17E for liquid or slurry.
- 5. Disposal Facility:
 - * Clean Water: Into sanitary sewer per Local Sewer District approval or into storm sewer with proper approval from Water Board.
 - * Non-Hazardous:
 - -Water with TPH and BTEX only.
 - -Water with free product.
 - -Arrange certified waste hauler to pick and dispose.
 - * Hazardous:
 - -Free product only.
 - -Arrange disposal by a certified hazardous waste hauler.

HEALTH AND SAFETY PLAN FOR LIVERMORE HONDA PROPERTY LOCATED AT 3800 FIRST STREET LIVERMORE, CALIFORNIA

GENERAL:

This Health and Safety Plan (HSP) contains the minimum requirements for the subject site field work. The field activities include drilling, soil sampling and water sampling. All personnel and contractors will be required to strictly adhere with this HSP requirements.

The objective of the HSP plan is to describe procedures and actions to protect the worker, as well as unauthorized person, from inhalation and ingestion of, and direct skin contact with potentially hazardous materials that may be encountered at the site. The plan describes (1) personnel responsibilities and (2) protective equipment to be used as deemed when working on the site. At a minimum, all personnel working at the site must read and understand the requirements of this HSP. A copy of this HSP will be on-site, easily accessible to all staff and government field representative.

HAZARD ASSESSMENT:

The major contaminants expected to be encountered on the project are gasoline and its hydrocarbon constituents. The anti-

cipated contaminants and their exposure standards are listed in Table 1. It is not anticipated that the potential levels of exposure will reach the permissible exposure limits (PEL) or threshold limit values (TLV). Inhalation and dermal contact are the potential exposure pathways. Protective clothing will be mandatory for field personnel specified in this Plan. In addition, respiratory protective devices are required to be worn by each person onsite or to be within easy reach should irritating odors be detected or irritation of the respiratory tract occur.

TABLE 1
EXPOSURE LIMITS OF ANTICIPATED CHEMICAL CONTAMINANTS
IN PARTS PER MILLION (ppm)

Contaminant	PEL	EL	ED	CL	TWA	STEL
Benzene*[skin] & [carc]	1	<u></u>			10	5
Ethylbenzene	100				100	125
Toluene [skin]	100	200	10 min per 8 hours	500	100	150
<pre>Xylene (o, m, & p iomers) [skin]</pre>	100	200	30 min per 8 hours	300	100	150

PEL - permissible exposure limit: 8 hours, time-weighted average, California Occupational Safety and Health Administration Standard (CAL-OSHA).

- excursion limit: maximum concentration of an airborne contaminant to which an employee may be exposed without regard to duration provided the 8 hours time-weighted average for PEL is not exceeded (CAL-OSHA).
- ED excursion duration: maximum time period permitted for an exposure above the excursion limit but not exceeding the ceiling limit (CAL-OSHA).
- CL Ceiling limit: maximum concentration of airborne contaminant which employees may be exposed permitted (CAL-OSHA).
- TWA time-weighted average: 8 hours, [same as threshold limit value (TLV)], American Conference of Governmental Industrial Hygienists (ACGIH).
- STEL short-term exposure limit: 15 minutes time-weighted average (ACGIH).
- [carc] substance identified as a suspected or confirmed carcinogen.
- [skin] substance may be absorbed into the bloodstream through the skin, mucous membranes or eyes.
- * Federal OSHA benzene limits given for PEL and STEL; STEL has a 50 minutes duration limit.

A brief description of the physical characteristics, incompatibilitie, toxic effects, routes of entry and target organs has been summarized from the NIOSH Pocket Guide to Chemical Hazards for the contaminants anticipated to be encountered. This information is used in on-site safety meetings to alert personnel to the hazards associated with the expected contaminants.

Benzene:

Benzene is a colorless, aromatic liquid. Benzene may create an explosion hazard. Benzene is incompatible with strong oxidizers, chlorine, and bromine with iron. Benzene is irritating to the eyes, nose and respiratory system. Prolonged exposure may result in giddiness, headache, nausea, staggering gait, fatigue, bone marrow depression or abdominal pain. Routes of entry include inhalation, absorption, ingestion and skin or eye contact. The target organs are blood, the central nervous system (CNS), skin, bone marrow, eyes and respiratory system. Benzene is carcinogenic.

Ethylbenzene:

Ethylbenzene is a colorless, aromatic liquid. Ethylbenzene may create an explosion hazard. Ethylbenzene is incompatible with strong oxidizers. Ethylbenzene is irritating to the eyes and mucous membranes. Prolonged exposure may result in headache, dermatitis, narcosis or coma. Routes of entry include inhalation, ingestion and skin or eye contact. The target organs are the eyes, upper respiratory system, skin and the CNS.

Toluene:

Toluene is a colorless, aromatic liquid. Toluene may create an explosion hazard. Toluene is incompatible with strong oxidizers. Prolonged exposure may result in fatigue, confusion, euphoria, dizziness, headache, dilation of pupils, lacrimation,

insomnia, dermatitis or photophobia. Routes of entry are inhalation, absorption, ingestion and skin or eye contact. The target organs are the CNS, liver, kidneys and skin.

Xylene Isomers:

Xylene is a colorless, aromatic liquid. Xylene may create an explosion hazard. Xylene is incompatible with strong oxidizers. Xylene is irritating to the eyes, nose and throat. Prolonged exposure may result in dizziness, excitement, drowsiness, staggering gait, corneal vacuolization, vomiting, abdominal pain or dermatitis. Routes of entry are inhalation, absorption, ingestion and skin or eye contact. The target organs are the CNS, eyes, gastrointestinal tract, blood, liver, kidneys and skin.

GENERAL PROJECT SAFETY RESPONSIBILITIES:

Key personnel directly involved in the investigation will be responsible for monitoring the implementation of safe work practices and the provisions of this plan are (1) the drilling project supervisor and (2) Soil Tech Engineering, Inc. (STE) project field engineer. These personnel are responsible for knowing the provisions of the plan, communicating plan requirements to workers under their supervision and regulatory agencies inspectors and for enforcing the plan.

The personnel-protective equipment will be selected to prevent field personnel from exposure to fuel hydrocarbons that may be present at the site. To prevent direct skin contact, the following protective clothing will be worn as appropriate while working at the site:

- 1. Tyvek coveralls.
- 2. Butyl rubber or disposable vinyl gloves.
- 3. Hard hat with optional face shield.
- 4. Steel toe boots.
- 5. Goggles or safety glasses.

The type of gloves used will be determined by the type of work being performed. Drilling personnel will be required to wear butyl rubber gloves because they may have long duration contact with the subsurface materials. STE sampling staff will wear disposable gloves when handling any sample. These gloves will be charged between each sample.

Personnel protective equipment shall be put on before entering the immediate work area. The sleeves of the overalls shall be outside of the cuffs of the gloves to facilitate removal of clothing with the least potential contamination of personnel. If at any time protective clothing (coveralls, boots or gloves) become torn, wet or excessively soiled, it will be replaced immediately.

Total organic vapors will be monitored at the site with a portable PID. Should the total organic vapor content approach that of the threshold limit value (TLV) for any of the substances listed in Table 1, appropriate safety measures will be implemented under the supervision of the site project engineer. These precautions include, but are not limited to, the following: (1) Donning of respirators (with appropriate cartridges) by site personnel, (2) forced ventilation of the site, (3) shutdown of work until such time as appropriate safety measures sufficient to insure the health and safety of site personnel can be implemented.

No eating, drinking or smoking will be allowed in the vicinity of the drilling operations. STE will designate a separate area on site for eating and drinking. Smoking will not allowed at the vicinity of the site except in designated areas. No contact lenses will be worn by field personnel.

WORK ZONES AND SECURITY MEASURES:

The Project Engineer will call Underground Service Alert (USA) and the utilities will be marked before any drilling is conducted on-site, and the borings will be drilled at safe distances from the utilities. The client will also be advised to have a representative on-site to advise us in selecting locations of borings with respect to utilities or underground structures. Soil Tech Engineering, Inc. assumes no responsibility to utilities not so located. The first 5 feet will be hand augered before any drilling equipment is operated.

Each of the areas where the borings will be drilled will be designated as Exclusion Zones. Only essential personnel will be allowed into an Exclusion Zone. When it is practical and local topography allows, approximately 25 to 75 feet of space surrounding those Exclusion Zones will be designated as Contamination Reduction Zones.

Cones, wooden barricades or a suitable alternative will be used to deny public access to these Contamination Reduction Zones. The general public will not be allowed close to the work area under any conditions. If for any reason the safety of a member of the public (e.g. motorist or pedestrian) may be endangered, work will cease until the situation is remedied. Cones and warning signs will be used when necessary to redirect motorists or pedestrians.

LOCATION AND PHONE NUMBERS OF EMERGENCY FACILITIES:

For emergency reasons, the closest facilities addresses and phone numbers are listed below:

Livermore Fire Department 911

Livermore Manor Convalescent (510) 447-2280
788 Holmes Street, Livermore, CA

ADDITIONAL CONTINGENCY TELEPHONE NUMBERS:

Poison Control Center	• •	٠	٠	٠	(800) 523-2222
Soil Tech Engineering Administrative Office	€ .	•	•	•	(408) 496-0265
CHEMTREC			٠		(800) 424-9300

NOTE: Only call CHEMTREC stands for Chemical Transportation Emergency Center, a public service of the Chemical Manufacturer's Association. CHEMTREC can usually provide hazard information, warnings and guidance when given the identification number or the name of the product and the nature of the problem. CHEMTREC can also contact the appropriate experts.

This Site Safety Plan has been reviewed by the project engineer, STE field personnel and all subcontractors.

Amendments or modifications to this Plan may be written on a separate page and attached to this Plan. Any amendments or modifications must be reviewed and approved by the personnel name above.

TYPES OF PROTECTIVE CLOTHING AND RESPIRATION THAT SHOULD BE USED AT HAZARDOUS WASTE SITES LIVERMORE HONDA PROPERTY LOCATED AT 3800 FIRST STREET LIVERMORE, CALIFORNIA

The degree of hazard is based on the waste material's physical, chemical, and biological properties and anticipated concentrations of the waste. The level of protective clothing and equipment worn must be sufficient to safeguard the individual. A four category system is described below.

LEVEL A

Level A consists of a pressure-demand SCBA (air supplying respirator with back mounted cylinders), fully encapsulated resistant suit, inner and outer chemical resistant gloves, chemical resistant steel safety boots (toe, shank, and metatarsal protection), and hard hat. Optional equipment might include cooling systems, abrasive resistant gloves, disposable oversuit and boot covers, communication equipment, and safety line. Level A is worn when the highest level of respiratory, skin, and eye protection is required. Most samplers will never wear Level A protection.

LEVEL B

Level B protection is utilized in areas where full respiratory protection is warranted, but a lower level of skin and eye protection is sufficient (only a small area of head and neck is exposed). Level B consists of SCBA, splash suit (one or two piece) or disposable chemical resistant coveralls, inner and outer chemical resistant gloves, chemical resistant safety boots, and hard hat with face shield. Optional items include glove and boot covers and inner chemical resistant fabric coveralls.

LEVEL C

Level C permits the utilization of air-purifying respirators. Level B body, foot, and hand protection is normally maintained. Many organizations will permit only the use of approved full-face masks equipped with a chin or harness-mounted canister. However, many sites are visited by personnel wearing a half-mask cartridge respirator.

LEVEL D

Level D protection consists of a standard work uniform of coveralls, gloves, safety shoes or boots, hard hat, and goggles or safety glasses.

Two basic types of respirators are air-purifying and air-supplying. Air-purifying respirators are designed to remove specific contaminants by means of filters and/or sorbents. Air-purifying respirators come in various sizes, shapes, and models and can be outfitted with a variety of filters, cartridges, and canisters. Each mask and cartridge or canister is designed for protection against certain contaminant concentrations. Just because a cartridge says it is for use against organic vapors does not mean that it is good for all organic vapors.

Air-supplying respirators are utilized in oxygen-deficient atmospheres (less than 19.5 percent) or when an air-purifying device is not sufficient. Air is supplied to a face-mask from an uncontaminated source of air via and air line from stationary tanks, from a compressor, or from air cylinders worn on the back (SCBA). Rated capacities of the SCBA's are normally between 30 and 60 minutes. Only positive pressure (pressure demand) respirators should be used in high concentration hazardous environments.

Respirators often malfunction during cold weather or after continued use. Only NIOSH (National Institute for Occupational Safety and Health) MSHA (Mine Safety and Health Administration) approved respirators should be used.

Contact lenses are not permitted for use with any respirator. Contact lenses should not be worn at any site since they tend to concentrate organic materials around the eyes; soft plastic contact

lenses can absorb chemicals directly. In addition, rapid removal of contact lenses may be difficult in an emergency. Since eye glasses can prevent a good seal around the temple when wearing goggles or full face masks, spectacle adapters are available for masks and goggles.

File No. 11-92-528-ST

 $\mathbf{A} \quad \mathbf{P} \quad \mathbf{P} \quad \mathbf{E} \quad \mathbf{N} \quad \mathbf{D} \quad \mathbf{I} \quad \mathbf{X} \quad \mathbf{^{11}}\mathbf{E^{11}}$

ALAMEDA COUNTY HEALTH CARE SERVICES AGENCY

DAVID J. KEARS, Agency Director

RAFAT A. SHAHID, ASST. AGENCY DIRECTOR

DEPARTMENT OF ENVIRONMENTAL HEALTH
State Water Resources Control Board
Division of Clean Water Programs
UST Local Oversight Program
80 Swan Way, Rm 200
Oakland, CA 94621
(510) 271-4530

StID 2937

January 27, 1993

Edwin Spencer 880 Columbine Ct Danville, CA 94526

Subject: PSA for Livermore Honda, 3800 First St., Livermore

Dear Mr. Spencer:

This office has completed review of the file for the above referenced site. When three underground storage tanks (USTs) were removed in December 1992, soil samples taken from native soil beneath the USTs exhibited up to 98 parts per million (ppm) total petroleum hydrocarbons as gasoline (TPH-G) and 95 ppm total oil and grease (TOG).

At this time additional investigations are required to determine the lateral and vertical extent, and severity of soil and ground water contamination which may have resulted from the unauthorized release of fuel products at this site. Such an investigation shall be in the form of a Preliminary Site Assessment, or PSA. The information gathered by the PSA will be used to determine an appropriate course of action to remediate the site, if deemed necessary. The PSA must be conducted in accordance with the RWQCB Staff Recommendations for the Initial Evaluation and Investigation of Underground Tanks, the State Water Resources Control Board LUFT Field Manual, and Article 11 of Title 23, California Code of Regulations. The major elements of such an investigation are summarized in the attached Appendix A.

The PSA proposal is due within 45 days of the date of this letter. Once the proposal is approved, field work should commence within 60 days. A report must be submitted within 45 days after the completion of this phase of work at the site. Subsequent reports are to be submitted <u>quarterly</u> until this site qualifies for RWQCB "sign off." All reports and proposals must be submitted under seal of a California Registered Geologist, Certified Engineering Geologist, or Registered Civil Engineer.

Enclosed is a UST Unauthorized Release/Contamination Site Report which must be completed within 15 days and returned to this office.

Please be advised that this is a formal request for technical reports pursuant to Title 23, CCR, Section 2722(c). Any extensions of the stated deadlines, or modifications of the required tasks, must be confirmed in writing by either this agency or the RWQCB. Copies of all proposals and reports must

E. Spencer re: Livermore Honda January 27, 1993

also be sent to Mr. Eddy So of the RWQCB.

Should you have any questions about the content of this letter, please contact me at (510) 271-4530.

Sincerely,

Eva Chu

Hazardous Materials Specialist

enclosures

cc: Eddy So, RWQCB

Gil Jensen, Alameda County District Attorney's Office

Danielle Stefani, Livermore Fire Department

Edgar Howell/files

hondal